

MOST OFTEN REQUESTED REPLACEMENT PARTS

JBX SERIES

MODELS:

JBX-151 · JBX-155 · JBX-455



DESCRIPTION

Battery Shim	25601600
Top Panel Assembly	13183004
Nut, 2.5mm jack	02802026
Nut, 3.5mm jack	02802027

PART

Housing JBX-151*

9/JBX-151-CASE

Inlcudes:	
Case Assembly, PTT w/Battery Door	13220004
Nameplate, Front Panel	14222018
Battery Contact	25500100
Grill Cloth	25601500
Speaker, Grill Cloth	25603300
Battery Shim	25601600
Foam Spacer	25601700
Labels	

Housing JBX-155*

9/JBX-155-CASE

Inlcudes:	
Case Assembly, PTT w/Battery Door	13220004
Nameplate, Front Panel	14222018
Battery Contact	25500100
Grill Cloth	25601500
Speaker, Grill Cloth	25603300
Battery Shim	25601600
Foam Spacer	25601700
Labels	

Housing JBX-455*

9/JMX-455-CASE

Inlcudes:	
Case Assembly, PTT w/Battery Door	13220004
Nameplate, Front Panel	14222018
Battery Contact	25500100
Grill Cloth	25601500
Speaker, Grill Cloth	25603300
Battery Shim	25601600
Foam Spacer	25601700
Labels	

DESCRIPTION

Battery Contact	25500100
Battery, 700 mAH, Ni-Cd	BPX-8N
Battery Charger, Wall	BC-A
Belt Clip	CBX-A
Bushing, Antenna	02500120
Door, Battery	13168000
Inlay, Top Panel	14222017
Jack, 2.5mm PC. Mount, Micro	02100339
Jack, 3.5mm Stereo 0.75	02100359
Gold Micron	
Jack Plug, Dual, Rubber	25601300
Knob, Channel	25800300
Knob, Volume	25800400
Manual/Oper, JBX-151	01451173
Manual, User, JBX-155/455	01451202
Microphone Basket, Rubber Spkr	25601400
Microphone, Minature	05500037

* For other parts not listed call 1-800-872-1872 or fax to 800-251-7329

Questions? Email your technical questions to tech@ritron.com. A Ritron technician will respond within 24 hours